



Barrier Free Architecturals
 480 E Franklin Rd, #108, Meridian, ID 83646
 1(877) 717-7027 or visit: www.barrierfree.org
 EMAIL: info@barrierfree.org

Installation Instructions

No-Caulk Shower Drain

Compression Gasket - Brass



Installation Instructions:

1. Remove Inside Compression Nut and Compression Gasket
2. Apply Silicone around the Shower Drain Hole on the inside of the shower only.
3. Install the Drain Body in the Shower Drain Hole
4. Install the Rubber Gasket, Fiber Gasket and the Locking Nut- Tighten.
5. Install the shower over the drain pipe, or install the pipe later.
6. Slide the Inside Compression Gasket into Drain Body and slip over pipe. Make sure that the beveled end of Inside Compression Gasket is facing up and is flush with pipe surface.
7. Tighten Inside Compression Nut into Drain Body using the provided tool.

